

PVH HYDRAULIC PARTS



PVH 45/57/74/98/131/141 PUMP

NO.	DESCRIPTION	PCS
1	CYLINDER BLOCK	1
2	VALVE PLATE	1
3	PISTON SHOE	9
4	RETAINER PLATE	1
5	BALL GUIDE	1
6	THRUST PLATE	1
7	DRIVE SHAFT	1
8	SWASH PLATE	1
9	METAL	2
10	RETAINER	2
11	SPACER	2
12	COIL SPRING	1
13	SWASH PLATE PIN	2