





PVP 16/23/33/38/41/48/60/76/100/140 SPARE PARTS

NO.	DESCRIPTION	PCS
1	CYLINDER BLOCK	1
2	PISTON SHOE	9
3	VALVE PLATE	1
4	RETAINER PLATE	1
5	BALL GUIDE	1
6	THRUST PLATE	1
7	DRIVE SHAFT	1
8	COIL SPRING	1
9	SNAP RING	1
10	RETAINER WASHER	2
11	PRESS PIN	3